

Spare Parts Catalog

AQUAMINI

CONTENTS

AMS04	03-04
AMS06/08	05-06

Spare Parts Picture

Electrical Spare Parts



① PC board (Heat)




② Round LED controller(Heat)



③ 4-way valve



④ Compressor capacitor



⑤ Transformer



⑥ Fan motor capacitor



⑦ Fan motor



⑧ Full set of sensors(Heat)



⑨ Compressor



⑩ Titanium heat exchanger(Heat)

Refrigerate System Spare Parts



⑪ Evaporator



⑫ High pressure protection switch



⑬ Low pressure protection switch




⑭ High pressure protection switch

Other Spare Parts



⑮ Water union




⑯ Water union gasket



⑰ Fan


AMS04



AMS04

No.	Spare parts	AMS04
Electrical Spare Parts		
1	PC board (Heat)	
2	Round LED controller(Heat)	
3	4-way valve	
4	Compressor capacitor	
5	Transformer	
6	Fan motor capacitor	
7	Fan motor	
8	Full set of sensors(Heat)	
Refrigerate System Spare Parts		
9	Compressor	
10	Titanium heat exchanger(Heat)	
11	Evaporator	
12	High pressure protection switch	
13	Low pressure protection switch	
14	High&low Pressure valve	
Other Spare Parts		
15	Water union	
16	Water union gasket	
17	Fan	

AMS06/08



AMS06/08

No.	Spare parts	AMS06	AMS08
Electrical Spare Parts			
1	PC board (Heat) PC board (Heat&Cool)		
2	Round LED controller(Heat) Round LED controller(Heat&Cool)		
3	4-way valve		
4	Compressor capacitor		
5	Transformer		
6	Fan motor capacitor		
7	Fan motor		
8	Full set of sensors(Heat) Full set of sensors(Heat&Cool)		
Refrigerate System Spare Parts			
9	Compressor		
10	Titanium heat exchanger(Heat) Titanium heat exchanger(Heat&Cool)		
11	Evaporator		
12	High pressure protection switch		
13	Low pressure protection switch		
14	High&low Pressure valve		
Other Spare Parts			
15	Water union		
16	Water union gasket		
17	Fan		